

DID YOU KNOW SALES TIPS

From **DSC®**

Night Arming Mode is now available on the New Power Series.

The New Power Series panels can now be armed in (3) different modes; armed in Away Mode (*perimeter and interior armed*), armed in Stay Mode (*perimeter armed, all interior disarmed*), and armed in Night Mode (*perimeter armed, some interior armed and some interior disarmed*).

Night Arming is useful when the customer goes to bed and wants to arm some areas of their interior (*i.e., basement and garage motion detectors*) but leave other areas of their interior disarmed (*i.e., main level motion detectors*).

How Night Arming works

When the customer arms in the Stay Mode, any zones defined as [05 –Interior Stay/Away], [06 –Delayed Stay/Away], or [37 –Night Zone] will automatically be bypassed and only the perimeter zones will be armed. This is done by pressing the [Stay] function button on the keypad or entering their access code and staying in the house. Arming in the Stay Mode allows the customer to walk freely around their house and not cause false alarms.

When the customer is ready to go to bed, they press [*][1] on the keypad. Any zone defined as [05 –Interior Stay/Away] or [06 –Delayed Stay/Away] will become armed, adding additional interior protection. Any zone defined as [37 –Night Zone] will remain bypassed. The customer MUST arm in the Stay Mode first before switching to the Night Mode.

How to program the Night Mode

- Program in section [001] thru [004] any zone that will be disarmed in the Stay mode and Night mode as [37 –Night Zone]. This will typically be for motion detectors in the main area of the house.
- Program in section [001] thru [004] any zone detector that will be disarmed in the Stay mode, but armed in the Night mode as [05 –Interior Stay/Away] or [06 –Delayed Stay/Away]. This will typically be for motion detectors in the basement and garage.

