

DID YOU KNOW SALES TIPS From **DSC®**

Daylight Saving Change

Effective 2007, Daylight Savings Time (DST) will no longer be observed between April to October, but instead between March to November. See the chart below:

DST Begins 2 a.m. (2nd Sunday in March). DST Ends 2 a.m. (1st Sunday in November)

2007 March 11 - November 4

2008 March 9 - November 2

2009 March 8 - November 1

2010 March 14 - November 7

2011 March 13 - November 6

2012 March 11 - November 4

2013 March 10 - November 3

2014 March 9 - November 2

2015 March 8 - November 1

PC1616/PC1832/PC1864/PC4020

These control panels have a configurable automatic DST adjustment date.

For the new DST, program the following:

PC1616/PC1832/PC1864

Step 1: Section [017], enable toggle#6

Step 2: Section [168], enter 003 002 000 002 001

Step 3: Section [169], enter 011 001 000 002 001

PC4020

Step 1: Ref# [00020303], enter 0312

Step 2: Ref# [00020304], enter 1111